



Verbatim microSD/miniSD Cellphone Reference Guide

Verbatim miniSD/microSD cards are compatible with any miniSD/microSD slot equipped device. And by using the adapter included, you can use the cards on any other SecureDigital equipped devices – such as Cameras, Card Readers and Computers - to capture your favorite video, photos, music and important data. Verbatim micro/mini SD cards can be used in the following cell phones:

microSD

Alcatel: E801

Blackberry: Curve, Pearl, 8800

HTC: MTeoR, P3350, P3300, P4350, S620, S720, Touch, TyTN, TyTNII

Kyocera: Slider Remix KX5

LG: Chocolate, Shine, Prada, Viewity, KU508, U330, U400, U890, U8550

Motorola: A630, A780, A840, A860, A1000, A1010, C975, E398, E770, E815, E1000, E1060, E1120, KRZR K1, MPC300, SLVR L7e, SLVR V8, RAZR V6, RAZR K1, RIZR Z3, V8, V635, V710, V975, V980, V1000, V1050, V1150, V3i RAZR

Nokia: 3250, 5300, 5310, 5610, 6110, 6120, 6121, 6131, 6151, 6233, 6234, 6267, 6300, 6500, 7373, 7390, 8600 Luna, E50, E65, E90, N800, N95

O2: Ice, XDA Orbit


Orange: SPV M3100

Palm One: Treo 680

Samsung: A800, D510, D600, D830, D840, D900, E250, E570, E770, E870, E900, F210, F300, F700, G600, i300, i600, i750, J600, P850, U600, U700, V300, V500, V510, X800, X810, Z110, Z300, Z400, Z500, Z560, Z630, Z650i, Z700, z720

Siemens: EF61 Mia, EL71

T-Mobile: MDA Compact, MDA Compact III, MDA Vario II





miniSD

Alcatel: OT-S853, S853

Fijitsu: F2102V, F505i, F505iGPS, F506i, F700i, F900i, F900iC, F900iT

Hitachi: A5403CA, A5406CA, A5407CA, W11H, W11K, W22H

HTC: Shift

i-mate: SP3, SP3i

Innostream: INNO 75

Kyocera: A5502K, PENCK, W11K, W31K

LG: 5350, C950, KP3500, M4300, MM-535, PG930, SD350, U8200, VX-1800, VX-9800

Mitsubishi: D505i, D901i, M430i, M790i, M900

Motorola: E724, MPx100, MPx220

NEC: 802N, N505i, N505iS, N506i, N700, N840, N900i, N900iG, N900iS, N901iC, N9001, N9001i

Nokia: 3620, 5500 Sport, 6280, 6288, 7700, E61, E70, N73, N80, N93

O2: X3, X4, Xphone II

Orange: SPV C500, SPV C600

Palm One: Treo 750v

Panasonic: MX7, P252i, P252is, P253i, P505i, P505is, P506C, P506iV, P900iV, 901i, SA7, VS7, X700, X800, Z800

Samsung: 2300, D700, i250, i600

Sanyo: 5600, A5505SA, ICR-S170M, ICR-S290RM, MM-5600, W21SA, W31SA

Sendo: X2

Sharp: J-SH52, SH505i, SH505iS, SH506iC, SH700i, SH900i, SH901iC

Siemens: E61, SX1, SX56, SX66, U10

Sierra Wireless: 8010, 8020

T-Mobile: MDA Vario, SDA Music Phone, Sidekick III, SDA phone

Toshiba: A5403CA, A5501T, A5502K, A5504T, A5506T, V602T, V603T, W21T

