

EXTERNAL CD/DVD BURNER

Mini USB Y-Cable Information

Verbatim's External Mobile CD/DVD Burner includes a Mini USB Y-Cable in the box. This type of cable is traditionally used for older computers that are unable to power devices such as optical drives from one port. In certain cases, you may also find that the burner will work on a single connection while reading disks, but may require you to plug in both USB connectors when burning discs, as this function requires more power.

When using this cable, please take note to connect it correctly, as per the images below.



CONNECTION 1

On a newer laptop/PC, connect the mini USB to the DVD Burner and the middle USB connector to the USB port on the host device.



CONNECTION 2

On an older laptop/PC, or where more power is required, connect the mini USB to the DVD Burner and the both USB connectors to USBs port on the host device.



INCORRECT CONNECTION

Connecting the mini USB to the burner and the 2nd USB connector (not middle one) will result in the burner failing to operate.

